




59



ZX  
590-000/1

1

# FONCTION BOITE DE VITESSES

*NOMENCLATURE DES PIECES  
LISTE DES SCHEMAS*





59



ZX  
590-0/30


3

4

ZX  
590-0/30



59






59



ZX  
590-0/30

5



590-0/30

590-0/30

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29




59



ZX  
590-1/30


3



590-1/30

590-1/30

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29






59



ZX  
590-1/30


3



590-1/30

590-1/30

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29








59



ZX  
590-1/35

3



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29




59



ZX  
590-1/40

3



590-1/40

590-1/40

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29




59



ZX  
590-2/30

5



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29




59



ZX  
592-1/30

3



592-1/30

592-1/30

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29